

---

# User Manual M1

Resistance values: 1 k $\Omega$ , 10 k $\Omega$ , 100 k $\Omega$ , 1000 k $\Omega$



## Technical features:

- red display of -1999...9999 digits (optional: green, orange or blue display)
- minimal installation depth: from 63 mm with plug-in terminal
- adjustment via factory default or directly on the sensor signal
- min-/max-value recording
- 10 adjustable setpoints
- display flashing at threshold exceedance or undershooting
- Tara function
- programming interlock via access code
- protection class IP65 at the front
- plug-in screw terminal
- pc-based configuration software PM-TOOL for devices without keypad, for a simple adjustment of standard devices

## Identification

STANDARD TYPES	ORDER NUMBER
Resistance values	M1-3VR4B.0x06.570AD
Housing size: 96x24 mm	M1-3VR4B.0x06.770AD

### Options – breakdown of order code:

	M	1-	3	V	R	4	B.	0	x	0	6.	7	7	0	A	D	
<b>Basic type M-Line</b>																	
<b>Installation depth</b> 74 mm incl. plug-in terminal																	<b>Dimension</b> D physical Unit
																	<b>Version</b> A Standard B Installation depth 63 mm only with 24 VDC supply
<b>Housing size</b> 96x24x60 mm (without plug-in terminal)																	<b>Setpoints</b> 0 no setpoints
<b>Display type</b> Current, voltage, Resistance																	<b>Protection class</b> 1 without keypad, operation on the back 7 IP65 / plug-in terminal
<b>Display colours</b> Blue Green Red Orange																	<b>Supply voltage</b> 5 230 VAC 7 24 VDC galv.insulated
<b>Number of digits</b> 4-digit																	<b>Measuring input</b> 6 Resistance
<b>Digit height</b> 14 mm																	<b>Analog output</b> 0 without
<b>Interface</b> without																	<b>Resistance value</b> 8 1 kOhm 5 10 kOhm 6 1000 kOhm 7 1000 kOhm

Please state physical unit by order, e.g. mm


---

## Contents

1.	Assembly	2
2.	Electrical connection	3
3.	Function and operation description	4
4.	Setting up the device	5
4.1.	Switching on	5
4.2.	Standard parameterization	5
4.3.	Extended parameterization	7
4.3.1.	Min/Max value inquiry „TRST“	8
4.3.2.	Flashing of display „FLAS“	8
4.3.3.	Threshold values „LI-1“ to „LI-2“	8
5.	Factory settings	11
5.1.	Default values	11
5.2.	Reset to default settings	12
6.	Technical data	13
7.	Safety advice	15
8.	Error elimination	16

## 1. Assembly

Please read the *Safety advice* on *page 15* before installation and keep this user manual for future reference.




1. After removing the fixing elements, insert the device.
2. Check the seal to make sure it fits securely.
3. Click the fixing elements back into place and tighten the clamping screws by hand. Then use a screwdriver to tighten them another half a turn.

**CAUTION!** The torque should not exceed 0.1 Nm!


The dimension symbols can be exchanged before installation via a channel on the side!

## 2. Electrical connection

**Type M1-3VR4B.0x06.570AD**  
with a supply of 230 VAC



**Type M1-3VR4B.0x06.770AD**  
with a supply of 24 VDC



### 3. Function and operation description

#### Operation

The operation is divided into two different levels.

#### Menu Level







Here it is possible to navigate between the individual menu items.


#### Parameterization level:

The parameters stored in the menu item can be parameterized here.

Functions that can be adjusted or changed are always indicated with a flashing of the display. Adjustments made at the parameterization level should be always confirmed by pressing the **[P]** key to save them.

However, the display automatically saves all adjustments and then switches to operation mode if no further keys are pressed within 10 seconds.

Level	Button	Description
Menu level		Change to parameterization level with the relevant parameters
	 	For navigation at the menu level
Parameterization level		To confirm the changes made at the parameterization level
	 	To change the value or setting



#### Programming via configuration software PM-TOOL-MUSB6

You receive the software on CD incl. an USB-cable with a device adaptor. The connection is done via a 6-pole micromatch connector plug on the back and the PC is connected via an USB connector plug.

System requirements: PC with USB interface

Software: Windows XP, Windows Vista

## 4. Setting up the device

### 4.1. Switching on












Once the installation is complete, you can start the device by applying the current loop. Check beforehand once again that all the electrical connections are correct.







### Starting sequence

For 1 second during the switching-on process, the segment test (8 8 8 8) is displayed, followed by an indication of the software type and, after that, also for 1 second, the software version. After the start-up sequence, the device switches to operation/display mode.

### 4.2. Standard parameterization:

To be able to parameterize the display, press the **[P]** key in operating mode for 1 second. The display then changes to the menu level with the first menu item *TYPE*.





Menu level	Parameterization level
	<p><b>Selection of the input signal, <i>TYPE</i>:</b></p> <p>SCAL  SENS  P</p> <p>As input versions, resistance values of 1, 10, 100 or 1000 kΩ signals as factory calibration (without connected sensor signal) and <i>SENS</i> (with connected measuring signal) as sensor calibration are available. Confirm with <b>[P]</b>. The display then switches back to the menu level again.</p>
	<p><b>Setting the final value of the measuring range, <i>END</i>:</b></p> <p>8 P 8 P 8 P 8  NOCR  CAL  P</p> <p>The final value is adjusted from the smallest to the highest place with <b>[▼]</b> <b>[▲]</b> and confirmed place selective with <b>[P]</b>. A minus sign can only be parameterized on the highest place. After the last place the display switches back to the menu level. If <i>SENS</i> has been selected, you can then choose between <i>NOCR</i> and <i>CAL</i>. At <i>NOCR</i> the before adjusted value will be taken over, at <i>CAL</i> the value alignment via the measuring section takes place and the analog input value is taken over.</p>
	<p><b>Setting the initial value of the measuring range, <i>OFFS</i>:</b></p> <p>8 P 8 P 8 P 8  NOCR  CAL  P</p> <p>The initial value is adjusted from the smallest to the highest place with <b>[▼]</b> <b>[▲]</b> and confirmed place selective with <b>[P]</b>. After the last place the display switches back to the menu level. If <i>SENS</i> has been selected, you can then choose between <i>NOCR</i> and <i>CAL</i>. At <i>NOCR</i> the before adjusted value will be taken over, at <i>CAL</i> the value alignment via the measuring section takes place and the analog input value is taken over.</p>





Menu level	Parameterization level
	<p><b>Setting the decimal place / sign of physical unit, <i>END</i>:</b></p>  <p>The decimal place and the physical unit are set with [▼] [▲]. Confirm with [P], the display then switches back to the menu level again.</p>
	<p><b>Setting the display time, <i>SEC</i>:</b></p>  <p>The display time is set with [▲] [▼]. The display moves up in increments of 0.1 up to 1 second and in increments of 1.0 to 10.0 seconds. Confirm the selection by pressing the [P] button. The display then switches back to the menu level again.</p>
	<p><b>Activation / deactivation of the programming lock and completion of the standard parameterization, <i>RUN</i>:</b></p>  <p>With the aid of the [▲] [▼] keys, you can choose between the deactivated key lock <b>ULOC</b> (works setting) and the activated key lock <b>LOC</b>. Make the selection with [P]. After this, the display confirms the settings with "- - -", and automatically switches to operating mode. If <b>LOC</b> was selected, the keyboard is locked. To get back into the menu level, you must press [P] for 3 seconds in operating mode. You must now enter the <b>CODE</b> (works setting 1 2 3 4) that appears using the [▲] [▼] keys plus [P] to unlock the keyboard. <b>FAIL</b> appears if the input is wrong.</p>



























### 4.3. Extended parameterization


By pressing the [▲] & [▼] buttons during standard parameterization for one second, the display switches to the extended parameterization mode. Operation is the same as in standard parameterization.

Menu level	Parameterization level
	<p><b>Rescaling of measuring input values, <i>END A</i>:</b></p> <p>With this function the final value e.g. 1500 <math>\Omega</math> (factory setting) can be rescaled without connecting of a measuring signals. At selected sensor calibration these parameters are not available.</p>
	<p><b>Rescaling of measuring input values, <i>OFF A</i>:</b></p> <p>With this function the initial value e.g. 500 <math>\Omega</math> (factory setting) can be rescaled without connecting of a measuring signals. At selected sensor calibration these parameters are not available..</p>
	<p><b>Setting of Tara- / Offset value, <i>TARA</i>:</b></p> <p>The preset value is add to the linearized value. This way, the characteristic line can be adjusted according to the selected value.</p>
	<p><b>Zero point slowdown, <i>ZERO</i>:</b></p> <p>With zero point slowdown, a value range around zero can be preselected at which the display shows zero. If, for example, a 10 is set, the display would show a zero in the range from -10 to +10 and continue below it with -11 and above it with +11.</p>

Menu level	Parameterization level
	<b>4.3.1. MIN/MAX value inquiry - Assignment of key functions, <i>TAST</i>:</b>  <p>Here, you can enter for the operating mode either a MIN/MAX value inquiry or a threshold value correction on the arrow keys.          If the MIN/MAX memory is activated with <b>EHER</b>, the measured MIN/MAX values will be saved during operation and can be called up via the arrow keys [▲] [▼]. The values are lost if the device is restarted. If the threshold value correction <b>LI.1</b> is selected, the limit values can be changed during operation without hindering the operating procedure. If <b>NO</b> is parameterized, the arrow keys [▼] [▲] have no function in operating mode.</p>
	<b>4.3.2. Flashing of display, <i>FLAS</i>:</b>  <p>Here, flashing of the display can be added as an extra alarm function, either to the first limit value (select: <b>LI-1</b>), the second limit value (select: <b>LI-2</b>) or to both limit values (select: <b>LI-12</b>). With <b>NO</b> (works setting), no flashing is assigned at all.</p>
	<b>4.3.3. Limit values / Limits, <i>LI-1</i>:</b>  <p>For both limit values, two different values can be parameterized. With this, the parameters for each limit value are called up one after the other.</p>
	<b>Hysteresis for limit values, <i>HY-1</i>:</b>  <p>For all limit values, a hysteresis function exists that reacts according to the settings (threshold exceedance / threshold undercut).</p>


Menu level	Parameterization level
<div data-bbox="124 412 284 465">Fu-1</div> <div data-bbox="308 412 359 465">P</div> <div data-bbox="134 533 274 645">   </div>	<p data-bbox="352 331 1129 360"><b>Function if display falls below / exceeds limit value, FU-1:</b></p> <div data-bbox="411 398 957 504"> <div data-bbox="411 412 571 465">HI 9H</div> <div data-bbox="579 398 630 504">   </div> <div data-bbox="654 412 813 465">LoUu</div> <div data-bbox="821 398 873 504">   </div> <div data-bbox="896 412 948 465">P</div> </div> <p data-bbox="352 548 1476 719">The limit value undercut can be selected with <b>LoUu</b> (LOW = lower limit value) and limit value exceedance can be selected with <b>HI 9H</b> (HIGH = upper limit value). If e.g. limit value 1 is on a switching threshold of 100 and occupied with function „<b>HIGH</b>“, the alarm will be activated by reaching the threshold. If the limit value is allocated to „<b>LOW</b>“, an alarm will be activated by undercut of the threshold.</p>
<div data-bbox="124 801 284 855">LI-2</div> <div data-bbox="308 801 359 855">P</div> <div data-bbox="134 855 274 967">   </div>	<p data-bbox="352 750 671 779"><b>Limit value /Limits, LI-2:</b></p> <div data-bbox="411 779 1072 884"> <div data-bbox="411 801 462 855">0</div> <div data-bbox="486 801 537 855">P</div> <div data-bbox="561 801 612 855">0</div> <div data-bbox="636 801 687 855">P</div> <div data-bbox="711 801 762 855">0</div> <div data-bbox="786 801 837 855">P</div> <div data-bbox="861 801 912 855">0</div> <div data-bbox="936 801 987 855">P</div> <div data-bbox="1011 779 1062 884">   </div> <div data-bbox="1086 801 1137 855">P</div> </div> <p data-bbox="352 936 1476 996">For both limit values, two different values can be parameterized. With this, the parameters for each limit value are called up one after the other.</p>
<div data-bbox="124 1093 284 1146">HY-2</div> <div data-bbox="308 1093 359 1146">P</div> <div data-bbox="134 1146 274 1258">   </div>	<p data-bbox="352 1025 791 1055"><b>Hysteresis for limit values, HY-2:</b></p> <div data-bbox="411 1070 1072 1176"> <div data-bbox="411 1093 462 1146">0</div> <div data-bbox="486 1093 537 1146">P</div> <div data-bbox="561 1093 612 1146">0</div> <div data-bbox="636 1093 687 1146">P</div> <div data-bbox="711 1093 762 1146">0</div> <div data-bbox="786 1093 837 1146">P</div> <div data-bbox="861 1093 912 1146">0</div> <div data-bbox="936 1093 987 1146">P</div> <div data-bbox="1011 1070 1062 1176">   </div> <div data-bbox="1086 1093 1137 1146">P</div> </div> <p data-bbox="352 1232 1476 1292">For all limit values, a hysteresis function exists that reacts according to the settings (threshold exceedance / threshold undercut).</p>
<div data-bbox="124 1411 284 1464">Fu-2</div> <div data-bbox="308 1411 359 1464">P</div> <div data-bbox="134 1509 274 1621">   </div>	<p data-bbox="352 1323 1134 1352"><b>Function if display falls below / exceeds limit value, FU-2:</b></p> <div data-bbox="411 1384 957 1489"> <div data-bbox="411 1406 571 1460">HI 9H</div> <div data-bbox="579 1384 630 1489">   </div> <div data-bbox="654 1406 813 1460">LoUu</div> <div data-bbox="821 1384 873 1489">   </div> <div data-bbox="896 1406 948 1460">P</div> </div> <p data-bbox="352 1534 1476 1675">To indicate if the value falls below the lower limit value, <b>LoUu</b> can be selected (LOW = lower limit value) and if it goes above the upper limit value, <b>HI 9H</b> can be selected (HIGH = upper limit value). LOW corresponds to the quiescent current principle and HIGH to the operating current principle.</p>
<div data-bbox="134 1809 293 1863">Code</div> <div data-bbox="308 1809 359 1863">P</div> <div data-bbox="134 1908 274 2020">   </div>	<p data-bbox="352 1704 663 1733"><b>Setting the code, CODE:</b></p> <div data-bbox="411 1787 1072 1892"> <div data-bbox="411 1809 462 1863">1</div> <div data-bbox="486 1809 537 1863">P</div> <div data-bbox="561 1809 612 1863">2</div> <div data-bbox="636 1809 687 1863">P</div> <div data-bbox="711 1809 762 1863">3</div> <div data-bbox="786 1809 837 1863">P</div> <div data-bbox="861 1809 912 1863">4</div> <div data-bbox="936 1809 987 1863">P</div> <div data-bbox="1011 1787 1062 1892">   </div> <div data-bbox="1086 1809 1137 1863">P</div> </div> <p data-bbox="352 1971 1476 2031">With this setting, it is possible to select an individual code (works setting <b>1 2 3 4</b>) for locking the keyboard. To lock/release the key, proceed according to menu item <b>RUN</b>.</p>

## Functional principle of the setpoints



### Limit value exceedance “HIGH”

By limit value exceedance the alarm S1-S2 is off below the threshold and on on reaching the threshold.



### Limit value undercut “LOW”

By limit value undercut the alarm S1-S2 is on below the threshold and switched off on reaching the threshold.

## Alarms / optical setpoint display

An activated set point can be optically indicated by flashing of the 7-segment display.

Functional principle of the alarms	
Alarm	Deactivated, display value
Threshold	Threshold/limit value for switch over
Hysteresis	Width of the window between the thresholds
Function	Limit value exceedance / limit value undercut

## 5. Factory settings

### 5.1. Default values

Parameter	Menu items				Default
TYPE	SCAL	SENS			SENS
End	1999	to	9999		1000
OFFS	1999	to	9999		0000
dot	0000	to	0.000		0
SEC	0.1	to	10.0		1.0
run	ULOC	LOC			ULOC
OFFA	1999	to	9999		
EndA	1999	to	9999		
OFFA	1999	to	9999		
EndA	1999	to	9999		
OFFA	1999	to	9999		
EndA	1999	to	9999		
OFFA	1999	to	9999		
EndA	1999	to	9999		
OFFA	1999	to	9999		
EndA	1999	to	9999		
tarA	1999	to	9999		0000
ZER0	00	to	99		0
LAST	no	ENTER	L1.12		no
FLAS	no	L1-1	L1-2	L1.12	no
L1-1	1999	to	9999		0200
HY-1	0000	to	9999		0000
Fu-1	Low	HI 9H			HI 9H
L1-2	1999	to	9999		0300
HY-2	0000	to	9999		0
Fu-2	Low	HI 9H			HI 9H
Code	0000	to	9999		1234

## 5.2. Reset to default values

To return the unit to a **defined basic state**, a reset can be carried out to the default values.

The following procedure should be used:

- Switch off the power supply
- Press button **[P]**
- Switch on voltage supply and press **[P]**-button until „- - -“ is shown in the display.

With reset, the default values of the program table are loaded and used for subsequent operation. This puts the unit back to the state in which it was supplied.

**Caution! All application-related data are lost.**

## 6. Technical data

Housing			
Dimensions			
96x48	96x24x60 mm (BxHxT)		
	96x24x74 mm (BxHxT) including plug-in terminal		
Panel cut-out			
96x48	92.0 <sup>+0.8</sup> x 22.2 <sup>+03</sup> mm		
Insulation thickness	up to 3 mm		
Fixing	snap-in screw element		
Material	PC Polycarbonate, black, UL94V-0		
Sealing material	EPDM, 65 Shore, black		
Protection class	standard IP65 (front), IP00 (back side)		
Weight	approx. 200 g		
Connection	plug-in terminal; wire cross section up to 2.5 mm <sup>2</sup>		
Display			
Digit height	14 mm		
Segment colour	red		
Display range	-1999 to 9999		
Setpoints	optical display flashing		
Overflow	horizontal bars at the top		
Underflow	horizontal bars at the bottom		
Display time	0.1 to 10.0 seconds		
Input	Measuring range	Measuring fault	Digit
0...1.1 kΩ	1 kΩ	0.5 % of measuring range	±1
0...11 kΩ	10 kΩ	0.5 % of measuring range	±1
0...110 kΩ	100 kΩ	0.5 % of measuring range	±1
0...1100 kΩ	1000 kΩ	0.5 % of measuring range	±1
Temperature drift	100 ppm / K		
Measuring time	0.1...10.0 seconds		
Measuring principle	U/F-conversion		
Resolution	approx. 18 Bit at 1 second measuring time		
Power pack	230 VAC +/- 10 % max. 6 VA 24 VDC +/- 10 % max. 1 VA		
Memory	EEPROM		
Data life	≥ 100 years		

<b>Ambient conditions</b>	
Working temperature	0...60°C
Storing temperature	-20...85°C
Weathering resistance	relative humidity 0-80% on years average without dew
<b>EMV</b>	EN 61326
<b>CE-sign</b>	Conformity to directive 2004/108/EG
<b>Safety standard</b>	According to low voltage directive 2006/95/EG EN 61010; EN 60664-1



## 7. Safety advice

Please read the following safety advice and the assembly *chapter 1* before installation and keep it for future reference.

### Proper use

The **M1-device** is designed for the evaluation and display of sensor signals.



**Danger! Careless use or improper operation can result in personal injury and/or damage to the equipment.**

### Control of the device

The panel meters are checked before dispatch and sent out in perfect condition. Should there be any visible damage, we recommend close examination of the packaging. Please inform the supplier immediately of any damage.



### Installation

The **M1-device** must be installed by a suitably **qualified specialist** (e.g. with a qualification in industrial electronics).

### Notes on installation

- There must be no magnetic or electric fields in the vicinity of the device, e.g. due to transformers, mobile phones or electrostatic discharge.
- The **fuse rating** of the supply voltage should not exceed a value of **6A N.B. fuse**.
- Do not install **inductive consumers** (relays, solenoid valves etc.) near the device and **suppress** any interference with the aid of RC spark extinguishing combinations or free-wheeling diodes.
- Keep input, output and supply lines separate from one another and do not lay them parallel with each other. Position “go” and “return lines” next to one another. Where possible use twisted pair. So, you receive best measuring results.
- Screen off and twist sensor lines. Do not lay current-carrying lines in the vicinity. Connect the **screening on one side** on a suitable potential equaliser (normally signal ground).
- The device is not suitable for installation in areas where there is a risk of explosion.
- Any electrical connection deviating from the connection diagram can endanger human life and/or can destroy the equipment.
- The terminal area of the devices is part of the service. Here electrostatic discharge needs to be avoided. Attention! High voltages can cause dangerous body currents.
- Galvanic insulated potentials within one complex need to be placed on a appropriate point (normally earth or machines ground). So, a lower disturbance sensibility against impacted energy can be reached and dangerous potentials, that can occur on long lines or due to faulty wiring, can be avoided.

## 8. Error elimination

	Error description	Measures
1.	<p>The unit permanently indicates overflow.</p> 	<ul style="list-style-type: none"> <li>• The input has a very high measurement, check the measuring circuit.</li> <li>• With a selected input with a low voltage signal, it is only connected on one side or the input is open.</li> <li>• Not all of the activated setpoints are parameterised. Check if the relevant parameters are adjusted correctly.</li> </ul>
2.	<p>The unit permanently shows underflow.</p> 	<ul style="list-style-type: none"> <li>• The input has a very low measurement, check the measuring circuit .</li> <li>• With a selected input with a low voltage signal, it is only connected on one side or the input is open.</li> <li>• Not all of the activated setpoints are parameterised. Check if the relevant parameters are adjusted correctly.</li> </ul>
3.	<p>The word "<b>HELP</b>" lights up in the 7-segment display.</p>	<ul style="list-style-type: none"> <li>• The unit has found an error in the configuration memory. Perform a reset on the default values and re-configure the unit according to your application.</li> </ul>
4.	<p>Program numbers for parameterising of the input are not accessible.</p>	<ul style="list-style-type: none"> <li>• Programming lock is activated</li> <li>• Enter correct code</li> </ul>
5.	<p><b>"ERR1"</b> lights up in the 7-segment display</p>	<ul style="list-style-type: none"> <li>• Please contact the manufacturer if errors of this kind occur.</li> </ul>
6.	<p>The device does not react as expected.</p>	<ul style="list-style-type: none"> <li>• If you are not sure if the device has been parameterised before, then follow the steps as written in <i>chapter 5.2.</i> and set it back to its delivery status.</li> </ul>

---

---

---